






PWP300SVX

Pos. No.	Part Description	Item #
01-2	Bottom Plate	202037
05	Impeller, Vortex	202115
07	Pump Housing	203016
07-1	O-Ring (Kit Only)	Kit
08	Oil Chamber Cover	203045
08-1	O-Ring (Kit Only)	Kit
09	Lip Seal Buna-N	202231
10	Shaft Sleeve	-
13	Mechanical Seal Buna-N	202270
14	Lower Ball Bearing	200958
17	Rotor w/Shaft 115V, 1 PH	203086
18	Stator Coil w/Casing 115V, 1 PH	200511
19	Governor Switch w/Switch Plate	202360
20	Upper Ball Bearing	200967
21A	Oil Chamber Housing	203018
21A-1	O-Ring (Kit Only)	Kit
21B	Motor Cover (Upper)	202368
22	Motor Cover Plate	-
23	Overload Protector 115V, 1 PH	202383
24	Capacitor 115V	202417
26	Pump Top Cover	202433
26-1	O-Ring (Kit Only)	Kit
27	Power Cable w/Gland, 115V, 1 PH	204258
27-1	O-Ring (Kit Only)	Kit
27-2	Oil Sensor Cable (Optional)	202763
27-2-1	O-Ring (Kit Only)	Kit
27-3	Oil Sensor Cap	203139
31D	Oil Sensor w/wire	202409
31E	Ground Wire w/Ring Terminal	203145

Pos. No.	Part Description	Item #
32	Power Cable Line Clip	203161
33	Oil Sensor Cable Line Clip (Opt)	
34	Handle	202517
35	Rod Bolts	202666
38	Discharge Nipple 3"	202534
38E	Discharge Elbow	202558
38E-1	Gasket, Discharge Elbow, Buna-N	203208
38F	Discharge, 2" NPT-M, 45 deg elbow	-
38F	Discharge Flange 3"	202545
38F-1	Gasket, Discharge Flange, Buna-N	202659
50-01-2	Screw for Bottom Plate	203216
50-07	Screw for Pump Housing	203238
50-08	Screw for Oil Chamber Cover	203219
50-11	Screw for Oil Fill	203218
50-11-1	O-Ring (Kit Only)	Kit
50-12	Screw for Pressure Check	203218
50-12-1	O-Ring (Kit Only)	Kit
50-19	Screw for Governor Switch	202693
50-19B	Screw for Gov. Switch Plate	-
50-22	Screw for Cover Plate	-
50-23	Screw for Overload	202700
50-27	Screw for Power Cable	203216
50-27-2	Screw for Oil Sensor Cap	203216
50-31E	Screw for Ground Wire	202692
50-32	Screw for Line Clip (power cable)	203214
50-33	Screw for Line Clip (oil sens cable) (Opt)	203214
50-34	Bolt for Handle	203219
50-38E	Bolt for Discharge Elbow	203267
50-38F	Bolt for Discharge Flange	203253
	O-Ring Kit - Buna N	202634